

# Mounting and Adjusting the Leveler

1. Loosen all the adjustment knobs.
2. Screw the leveler on to the tripod with the tripod threaded rod (**hand tight only**)
3. Screw the Main Support Stud into the bottom of the jib by rotating the top plate (**hand tight only**)
4. Loosen the adjustment knob on the side you want to lower first.
5. Tighten the adjustment knob on the side you want to raise until it contacts the bottom plate and all the play is taken out of the assembly. (**Hand tighten only**)
6. Perform the same adjustments in the second axis

**Note:** It is extremely important to note that any time you tighten or raise one side of the leveler you must (**at the same time**) loosen the adjustment knob on the other side. If you tighten just one side, **it is possible to over stress the Mounting Stud to the point of failure**

